

**FITTING INSTRUCTIONS FOR SUZUKI GSX600F (W-0N)**  
**REPLACEMENT COLLECTOR -DS6WC**

This system is comprised of:           1 x Q1DS6W collector  
  1 x Clamp (E01031 59-63mm)

**MOTAD strongly recommend that this system be fitted by a recognised dealer.**

**YOU MAY NEED A NEW SILENCER TO COLLECTOR GASKET IN**  
**ORDER TO FIT THIS SYSTEM.**

N.B.

The collectors on this system are made from stainless steel. Please refer to the Care and Cleaning Instructions

1. Place the motorcycle on the side stand, centre stand if fitted.
2. remove the lower fairing on both sides.
3. Undo the bolt located at the front of the silencer and retain, slacken the clamp bolt on the collector.
4. Undo the hanging bracket nut and bolt and remove the silencer retaining the nut and bolt.
5. Undo and retain the nuts holding the collector to the cylinder head and remove the collector. Remove the gasket from the collector outlet and fit it to the Motad collector.
6. Loosely bolt the Motad collector to the cylinder head and fit the supplied clamp to the outlet. (DO NOT TIGHTEN)
7. Slide the silencer into the collector loosely bolting the hanging bracket to the inside of the footrest hanger.
8. Tighten the cylinder head bolts, the hanging bracket nut and bolt and the clamp on the collector.
9. Run the engine and check for any leaks.

**IF YOU HAVE ANY PROBLEMS FITTING THIS SYSTEM DO NOT**  
**HESITATE TO CALL US**

